



# SunnCamp

## FREEDOM PORCH

*Thank you for purchasing the Freedom Porch from SunnCamp.*

*Before erecting this porch, carefully read and understand these instructions. If there is anything you do not understand, contact your retailer for advice.*

*By following the instructions on erecting, dismantling, packing and storing the porch you will enjoy many years of trouble free use.*



### PARTS LISTING

The Freedom Porch consists of the following items and you should check everything is present before setting off.

<b>Flysheet</b>	<b>1</b>
<b>Adjustable pole</b>	<b>2</b>
<b>Fixed length pole</b>	<b>1</b>
<b>Two way angle</b>	<b>2</b>
<b>Pole end sucker</b>	<b>2</b>

It is a requirement of the warranty that you unpack and erect this porch at home prior to proper use. This will enable you to familiarise yourself with the porch and check all parts are present and in good condition. If you find any part missing or a fault with your porch, contact the retailer before returning or using it.

### GETTING STARTED

Unpack the porch and place the carry-bag somewhere safe. Separate all components and check that everything is present.

### POLES

Take the fixed length pole and slot sections together. Fit one two way angle and one sucker to either end of both adjustable poles.

The Poles are folded down to aid storage. When fitting the pole sections together, make sure that the pole tubes are firmly slotted together.

### PORCH FLYSHEET

With the adjustable tapes at the bottom of the flysheet fully loosened off, start to slide the beaded top rear edge into the caravan's awning channel. Once started also feed the two beaded tabs at the end of the adjustable tapes into the caravans bottom awning skirt channel (Please note that these tabs are fitted to the tapes with guyline loops, on first fitting it may be necessary to remove these and feed the tapes directly through the tabs eyelet). Position the Porch in place over the caravan's door.

Feed the fixed length pole through the sleeving at the front edge of the flysheet and attach an adjustable pole to either end utilising the two way angles. Ensuring both poles fit through the fabric loops at the rear of the flysheet, extend the poles and secure with their Quick Lock Brackets.

Finally tension the fabric by tightening the adjustable tapes at the bottom of the flysheet. In a small amount of cases where there is a lower distance between the caravans top and bottom rails it may be necessary to peg this point.

### WARRANTY

This porch is covered by a 12 month warranty. The Company undertakes to replace or repair, free of charge, any defect which the Company considers to be due to faulty workmanship or material within 12 months of the purchase date, except for:

- Defects arising from neglect, misuse or unauthorised modifications.
- Damage caused by storm, abuse, misuse, dropping or other similar damage caused by or as a result of failure to follow storage or erection instructions.
- Unauthorised alterations, additions or repairs.
- Transportation or shipment costs to and from the Manufacturer or their recognised agents, for repair or assessment against a warranty claim.
- Damage caused due to UV degradation.
- Materials and/or labour costs to renew, repair or replace components due to fair wear and tear or condensation.
- Tents used on permanent sites or displays.

**THIS DOES NOT AFFECT YOUR STATUTORY RIGHTS.**  
The Manufacturer and/or their recognised agents, directors, employees or insurers will not be held liable for consequential or other damages, losses or expenses in connection with or by reason of or the inability to use the tent for any purpose.

NOTE; Any claim(s) arising due to missing parts or faulty goods MUST be made before use. The manufacturer will not be responsible for any claims regarding missing parts or faulty items where the product has not been checked by the user prior to use.